

USER MANUAL

High-End Vehicle Video Monitoring System



Y S 0 1


D A S H C A M E R A

CONTENTS

- 1 Product Description
- 2 Functions & Indicators
- 3 Unit Interface
- 4 Mobile APP Connection
 - 4.1 Download the APP
 - 4.2 Connect to Wi-Fi and start the APP
 - 4.3 APP preview interface
- 5 Packing List
- Warranty Commitment

1. Product Description

This dash cam uses a high-performance chipset to deliver high-definition video with smooth, seamless footage. Please read this manual carefully before use and keep it in a safe place for future reference. We hope this product meets your needs and serves you well for a long time.



1. Bracket

2. Screen

3. USB Type-C

4. TF Socket


5. Rear Cam Socket

6. Speaker

7. Camera

8. Power Button

2. Functions & Indicators




1. Power Button

Short press to turn on.

After powering on: short press to switch screen views; long press for 15 seconds to restore factory settings.

3. Unit Interface

When the car engine is started, the dash camera automatically powers on and begins recording.



1. Recording Icon. Flashes once per second while recording; stops flashing when recording stops.

2. Audio Recording. A muted microphone icon indicates that audio recording is off; a microphone icon indicates that audio recording is on.

3. Wi-Fi Icon. A white Wi-Fi icon appears when Wi-Fi is on. When the mobile APP is connected, the Wi-Fi icon turns green.

4. TF Card Status. A crossed-out card icon indicates that no card is inserted or the card is faulty; a normal card icon indicates that the card is working properly.

5. APP. Scan to download the APP onto your mobile phone. Tap the side button of the device to switch screens.

6. Time/Date. Shows the current time and date.

4. Mobile APP Connection

4.1 Download the APP

Use your mobile browser to scan the QR code below to download the APP (the same APP works on both Android and iOS).



4.2 Connect to Wi-Fi and start the APP

Recorder Wi-Fi name: SUNLINK-XXX-XXXX Password: 12345678

After connecting, start the APP, tap to add a recorder, and connect to the dash cam.

4.3 APP Preview Interface

1. Recording status
2. Real-time picture
3. Front and rear video switching
4. Recording button
5. Photo button
6. Full screen preview
7. Recording switch
8. Recorder playback
9. Recorder settings



5. Packing List

Contents	Quantity
YS01 dash cam	1
Power cable (USB Type-C)	1
User manual	1
Rear cam	1

Warranty Commitment

1. Free repair within one year.

Within one year (inclusive) of the date of purchase, if the product fails to operate correctly due to a performance defect, you may return the faulty product together with all its accessories to the local sales office for repair.

2. From the date of purchase, free warranty service is not available in any of the following cases:

The warranty period has expired;

Malfunction or damage caused by failure to use, maintain, or store the product in accordance with the instruction manual;

No valid warranty certificate or invoice can be provided to prove that the product is still within the warranty period;

Unauthorized alteration of the warranty certificate;

The model shown on the warranty certificate does not match the actual product;

The product has been disassembled by the consumer;

Failure or damage caused by force majeure;

Faults or damage not caused by product design, technology, manufacturing, or quality issues.

Model: _____

Body number: _____

Production Date: _____

Customer Name: _____

Date of purchase: _____

Contact address: _____

Zip code: _____

Contact number: _____

Please ensure that the information above is accurate.

Customer Signature: _____