

USER MANUAL

High-End Vehicle Video Monitoring System



Y S 0 4


D A S H C A M E R A

CONTENTS

- 1 Product Description
- 2 Functions & Indicators Description
 - 2.1 Buttons Function
- 3 Unit Interface Introduction
 - 3.1 Main Interface Introduction
 - 3.1.1 Interface Display Introduction
- 4 Mobile APP Connection Introduction
 - 4.1 Download APP
 - 4.2 Connect to Wi-Fi and start APP
 - 4.3 Introduction to APP Preview Interface
- 5 Packing List
- Warranty Commitment


1. Product Description

Our dash cam adopts a high-performance chipset to provide high-definition video and seamless dynamic images. Please read this manual carefully before use and keep it in a safe place. We hope this product meets your needs and serves you for a long time!



- | | |
|--------------------|--------------------|
| 1. Bracket | 5. Rear Cam Socket |
| 2. Screen | 6. Speaker |
| 3. USB Type-C port | 7. Camera |
| 4. TF Socket | 8. Power Button |

2. Functions & Indicators Description



2.1 Buttons Function

1. Power Button

Short press to power on; long press to power off.

After booting: short press to switch views (front video, rear video, APP-download QR code, lock-screen clock).


Double-click (press twice quickly) to restore factory settings.

If it is a new card, use a short press on the phone to format the card.

3. Unit Interface Introduction

When the car engine starts, the recorder powers on automatically and turns on the recording function. If the rear camera is connected, the device enters the streaming-media interface by default; otherwise it enters the main interface.

3.1 Main Interface Introduction



3.1.1 Interface Display Introduction

1. Recording Icon: Flashes once per second while recording; stops flashing when recording stops.

2. Audio Recording:  indicates audio recording is off;  indicates audio recording is on.

3. Wi-Fi Icon: A white Wi-Fi icon appears when Wi-Fi is on. If connected to a mobile app, the Wi-Fi icon turns green.

4. TF Card Status:  indicates no card inserted or card malfunction;  indicates the card is normal.

5. APP: The APP downloaded on the mobile phone.

6. Time/Date

Download the app. Tap the button on the side of the device to switch screens.

4. Mobile APP Connection Introduction

4.1 Download APP

Use your mobile browser to scan the QR code below to download the APP (Android and iOS are the same).



4.2 Connect to Wi-Fi and start APP

Recorder Wi-Fi name: SUNLINK-XXX-XXXX Password: 12345678

After connecting, start the APP, tap to add a recorder, and connect to the recorder.

4.3 Introduction to APP Preview Interface

1. Recording status
2. Real-time picture
3. Front and rear video switching
4. Recording button
5. Photo button
6. Full screen preview
7. Recording switch
8. Recorder playback
9. Recorder settings



5. Packing List

Contents	Quantity
YS04 dash cam	1
Power Cable (USB Type-C)	1
Rear cam	1
User Manual	1

Warranty Commitment

1. Free repair within one year.

Within one year (inclusive) from the date of sale, if the product does not work properly due to performance defects, you may send the faulty product together with all its items to the local sales office for repair.

2. From the date of sale, free service cannot be enjoyed if the product fails due to one of the following reasons:

The warranty period has expired;

Failure or damage caused by not using, maintaining, or storing the product according to the requirements of the instruction manual;

No valid warranty certificate or valid invoice can be provided to prove that the product is within the warranty period;

Altering the warranty certificate without authorization;

The product model on the warranty certificate does not match the actual product;

The product has been disassembled by the consumer;

Failure or damage caused by force majeure;

Faults or damages not caused by problems in product design, technology, manufacturing, quality, etc.

Model: _____

Body No: _____

Production Date: _____

Customer Name: _____

Date of purchase: _____

Contact address: _____

Zip code: _____

Contact number: _____

Please ensure the information above is accurate.

Customer signature: _____